



## **ALSONIC RAVM MC**

Open channel radar flow meter

# **ALSONIC**

## **GENERAL**

SmartMeasurement's ALSONIC RAVM-MC is a combined radar velocity and level transducer used with our multi-channel controller (MC) which may include a number radar velocity (VS) transducers to provide a true non-intrusive approach to open channel area velocity measurement in channels having widths of up to 500 m. The Alsonic-RAVM-MC can also be configured with up to 32 standalone radar velocity (VS) and/or velocity/level (VL) transducers in series in order to accurately profile large open channel systems (please see diagram on page 2.) The system is designed for continuous non-intrusive flow measurement of rivers, streams, municipal wastewater, and storm water channels. Users can also install a number of radar velocity (VS) transducers in combination with our radar level transducers (RL) which provides the same measurement as the combined VL/VS system. For channel widths of up to 10 meters, a cost-effective single channel system (SC) is recommended. The Alsonic RAVM-MC requires a multichannel controller with configuration software and MODBUS output to be configured in the control room on a standalone PC. MODBUS data includes flow, velocity, and height as well as sensor diagnostics. In applications where users want to install another level measurement technology (other than radar), either a single or multiple ALSONIC radar velocity transducers can be used for velocity profiling across the channel in combination with the level transducer by sending the outputs to our multichannel controller (MC) to perform the Area • Velocity flow calculation.




Alsonic RAVM VL

### **FEATURES**

- Can be configured with up to 32 non contact velocity transducers to profile large channels of up to 500 meters width
- Easy installation and maintenance
- Standard remote flow computer and touch screen option
- Bi directional velocity measurements
- User friendly setup and diagnostic software
- Micro power consumption
- Eliminates swing interference caused by wind and/or weather
- · Optional surcharge water level sensor

#### ALSONIC RAVM MC



### **SPECIFICATIONS**

Velocity transducer (VS)



Range: 0.15~15m/s
Accuracy: ±0.01m/s, ±1%

• Frequency: 24GHz

• Power supply: 6~24V<sub>DC</sub>, <80mA

• Output: RS485/Modbus

• Install angle: α=45°

• Beam angel: α2=12°, β2=25°

• Protection: IP67

• Dimensions: 100x100x50mm

#### Level transducer (RL)



• Level: -26GHz, 1.2~30m,  $\alpha_1$ =12°,  $\beta_1$ =12°

- 24GHz, 1.2~30m, α<sub>1</sub>=5°, β<sub>1</sub>=10°

- 24GHz, 0.4~30m,  $\alpha_1$ =8°,  $\beta_1$ =8°

- 60GHz, 0.25~7m, α<sub>1</sub>=7°, β<sub>1</sub>=7°

Accuracy: ±3mm, ±1%FS

• Power supply: 8~16V<sub>DC</sub>, <12mA

• Comunication: RS485, 4-20mA, SDI12

• Protection: IP67

• Dimensions: 100x100x50mm

#### Multichannel controller (MC)



• Input: RS485 up to 32

• Power supply: 5~17V<sub>DC</sub>, 5mA@12V

• Output: Velocity, level, flow,

Datalogger, 4~20mA, 2 relays (8A@250V<sub>AC</sub>, 5A@30V<sub>DC</sub>)

• Comunication: RS485, Modbus


• Protection: IP54

• Dimensions: 145x90x41mm

SmartMeasurement Tel: +1 414 299 3896 | Fax: +1 414 433 1606 Page: 1

## **DIMENSIONS**

Alsonic RAVM - multichannel flow/velocity



# **APPLICATIONS**













### MOUNTING SYSTEM

#### Mounting Plate, Spring Ring and Scissors Rings.

All sensors can be attached to a mounting plate or spring and scissors rings to install the sensors in minutes, thus reducing time in the manhole. The sensor is first attached to a carrier which can then slide onto any of the compatible mounting systems. This maintains a height suitable for measuring flow rates and velocities at very low water levels. To install the sensors in rectangular, trapezoidal or earthen channels, we recommend the sensor mounting plate. Stainless steel spring rings simplify sensor installation in cylindrical pipes. Standard diameter sizes from 150 mm (6 inches) to 600 mm (24 inches) are available. You can install the sensor and fasten the cable to the downstream edge of the ring in place before entering the manhole. The self-expanding device is tightened by expanding the band for a friction fit inside of the pipe. The adjustable scissors ring is installed in large diameter pipes from 500 mm (20 inches) to 1800 mm (72 inches) in diameter. It consists of a base section, one or more pairs of extensions to fit the size of the pipe, and a scissors mechanism.



### **CONFIGURATION SOFTWARE**



# **ALSONIC**

## Open channel radar flow meter ALSONIC RAVM MC

TYPE OF FLUID FULL SCALE FLOW CHANNEL SHAPE AND DIMENSIONS

CHANNEL MATERIAL

Please provide the name of your fluid media, the operating PH, and conductivity Please provide the max and min flow rate, in units of CMH, GPM or LPM, etc.

Please provide channel shape and dimensions including maximum and minimum level

Channel material such as concrete, fiber glass, mud

ALSONIC RAVM-								TRANSDUCER STYLE
Velocity + level sensor, width 0.8~12m (level 1.2~30m), 6~24V <sub>DC</sub> , RS485	000	VI						Multi-Channel
evel sensor, width 0.8~12m (level 1.2~30m), ~24V <sub>DC</sub> , RS485								Flow
Velocity sensor, 6~24V <sub>DC</sub> , 4-20mA, RS485							Velocity Transducer - up to 32psc	
Solar power supply Multichannel controller up 32 transducers (maximum channel width 500 meters) including RS485 and configuration software, IP54							Multi-channel controller	
Solar power supply SL				SL				
6~24 V <sub>DC</sub>					DC			Power supply
90~245 V <sub>AC</sub> , 50/60Hz AC								
None options					NN		Power supply	
Extreme cold style					ВС			
Configuration software program					Config			
Display module for MC controller						DP		
LORA						LO		
Bluetooth					BT			
RTU data logger					DL			
Lighting rod					LR			
Installation tool and accessories					IS			
RoHS approval					RP			
IP68 Protection					68			



VERSION20242503